

1



2



3



4



5



6



No.	Type	Material	Colour	Gap Between Boards mm	Number of Clips per Pack	Number of Clips Needed per sq/m	Clip Code	Screws Included	Screw Code	Number of Screws per Pack
1	Starter Clip	Stainless Steel	Silver	0	10	N/A	66SC01	Yes	N/A	N/A
2	Double Clip	Stainless Steel	Silver	1.5*	50	18	66DC01	Yes	N/A	N/A
3	Double Clip	Plastic	Black	7	100	18	70FCP01	Yes	N/A	N/A
4	Starter Clip	Stainless Steel	Black	7	1	N/A	71SC003	No	71SS003	100
	Starter Clip	Stainless Steel	Black	0	25	N/A	71SC003P	No	71SS003	100
5	Double Clip	Stainless Steel	Black	7	1	18	71DC003	No	71SS003	100
	Double Clip	Stainless Steel	Black	7	100	18	71DC003P	No	71SS003	100
6	Double Clip	Nylon	Black	7	100	18	71DCN003P	No	71SS003	100

*Except Classic boards where the gap is 5mm. For screw driver bit use code: **66TX001**.

NB. We recommend 9 clips per board length when using Natural and Classic boards and 12 clips per board length when using Victoria boards.

We also recommend using 10 starter clips per perimeter/starter board across the range.